

LL64 INSTRUCTIONS



1-800-272-0170

www.lunasea.com

Transmitter



Transmitter Functions


Transmitter is a wearable device that has a approx 5 year battery built in. When transmitter comes in contact with water it will send a signal to the receiver alarm which will sound audible and visual alarm.

Locking Wrist Strap

After threading the nylon strap through safety device and back through the locking connector, turn locking button 90 degrees as shown using a coin or screwdriver.



Receiver/Alarm



Charging Receiver

Make sure the unit is fully charged by placing it standing up on a charge pad. Then wait until Charging Light goes off.



Turn Receiver On

Momentarily press On/Off Button to turn on. Unit initializes and then Ready indicator blinks showing unit is in normal operation.

Low Battery

When battery becomes low the Low Bat Indicator will Blink. Place unit on Charge Pad until battery is fully charged. Charging light will then go off indicating full charge.

Pairing Receiver with Transmitter

Press and hold the Check Button for 5 seconds then with wet fingers, wet cloth or dipped in water across both gold pins. You will see Pairing indicator blink multiple times showing the device has been paired. You can do this with up to 25 transmitters.

To delete all pairing information, press and hold the Check Button for 10 seconds. This will erase all pairing memory. You may now pair new units to the receiver.



Check Button



Gold Pins

Alarm in Progress

When Transmitter comes in contact with water the Strobe Light on the Receiver activates and a Loud Alarm activates. As soon as gold pins are dry the device stops transmitting, however the Receiver Alarm will continue to sound alarm. To reset the Receiver, press the Pair/Reset Button or the On/Off Button.

If On/Off Button is pressed the unit will be in off state and will no longer monitor.



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.